## Honeywell

## Series TLEX

THERMOSTATIC EXPANSION VALVES FIXED ORIFICE, ADJUSTABLE SUPERHEAT SETTING, BALANCED PORT

#### PRODUCT DATA



### Application

Thermostatic expansion valves series TLEX are used in plants with one or more refrigerant circuits, in particular for series installations such as chiller units, heat pumps, and transport cooling.

#### **Materials**

Body	brass
Thermal head	stainless steel
Connection tubes	copper

#### **Features**

- Damped gas charge with MOP as standard
- Optional available with liquid charge •
- Adjustable superheat setting •
- Warm thermal head provides best reliability .
- Solder connections
- **External pressure equalisation**
- Extreme durable due to stainless steel head and stainless steel diaphragm welded using protective gas
- **Balanced port construction**
- **Fixed orifice**
- Refrigerants: R134a, R22, R407C, R404A Further refrigerants on request.

## **Specification**

**Bulb diameter** 

Nominal capacity range	21.5 to 52.3 kW R22
Evaporating temperature	
range	see table on page 2
Maximum pressure PS	29 bar
Maximum test pressure	32 bar (simultaneous on all connections)
Max. ambient temperature	100 °C
Max. bulb temperature	gas charge: 140 °C liquid charge: 70 °C
Static superheat	approx. 3.5 K
Length of capillary tube	2 m

16 mm

Copyright © 2003 Honeywell GmbH • Subject to change without notice

## Thermal Charges and Temperature Ranges

#### 1. Gas charges with pressure limiting MOP

Refrigerant	Evaporation temperature range	МОР
R134a	+15 °C to -40 °C	MOP +15 °C
	+10 °C to -40 °C	MOP +10 °C
R22	+15 °C to -45 °C	MOP +15 °C
	+10 °C to -45 °C	MOP +10 °C
R407C	+15 °C to -30 °C	MOP +15 °C
R404A	+10 °C to -45 °C	MOP +10 °C

Further refrigerants and MOP on request.

MOP valves protect the compressor by limiting the increase of suction pressure.

The MOP value should be chosen for the max. permissible suction pressure of the compressor or min. 5 K higher than the required evaporating temperature of the system.

With gas charged valves and MOP it is under all operating conditions necessary that the bulb is always colder than the capillary tube and the thermal head!

With the Honeywell TLEX series the thermal head is heated advantageously by the liquid refrigerant. The warm thermal head is on the safe side at any time.

## Capacities

		Nominal capacity (kW)*							
Туре	Orifice size	R134a	R22	R404A	R407C				
	4.75	15.0	21.5	16.2	21.5				
	5	18.8	27.9	21.0	27.9				
ILEA	6	26.0	40.7	30.6	40.7				
	7	33.3	52.3	39.3	52.3				

\* Capacities are based on to = -10 °C, tc = +25 °C and 1 K subcooled liquid refrigerant entering the valve. For other operating conditions see capacity charts in Honeywell catalogue or consult the Honeywell software.

### **Dimensions and Weights**

Туре	Orifice		Weight		
	size	Inlet (A)	Outlet (B)	Pressure equaliser (C)	(kg)
	4.75	12 mm ODF	16 mm ODF	6 mm ODF	
TLEX	5	1/2" ODF	5/8" ODF	1/4" ODF	
	6	16 mm ODF	22 mm ODF	6 mm ODF	approx. 0.66
	7	5/8" ODF	7/8" ODF	1/4" ODF	

#### 2. Liquid charge

#### Refrigerants on request.



## Type Code / Order Information

	TLEX	6	R22	MOP +15 °C	16 mm x 22 mm
Series					
Orifice size					
Refrigerant	·				
Gas charge with MOP () = liquid charge without MOP		 			
Solder connection ODF (inlet x outlet)	]				

#### Installation

- The valves may be installed in any position.
- The external pressure equaliser line should be 6 mm or 1/4" in diameter and is to be connected downstream of the remote bulb. An overbow is recommended in order to prevent the ingress of oil into the equaliser line.
- The bulb should preferably be positioned on the upper half of a horizontal suction line but never after a liquid trap. As a general rule, bulbs of expansion valves should be insulated to prevent them being affected by the ambient temperature.
- When soldering the valve, the valve body must not get warmer than 100 °C.
- Do not bend or squeeze the bulb when thightening the bulb clamp!
- · Constructive modifications at the valve are not allowed.

Information for original equipment manufacturers: The valve series TLEX can be customised to the requirements of your series device in an optimum way. Contact us!

## Superheat Adjustment

In general the valves should be installed with the factory setting for the used refrigerant unaltered. This setting is calibrated for lowest superheating and optimum evaporator utilization. However, should it be necessary to adjust the superheat, turn the adjusting spindle as follows:

Turning clockwise	=	reduced refrigerant mass flow, increase of superheat
Turning counterclockwise	=	increased refrigerant mass flow, decrease of superheat

One turn of the adjusting spindle alters superheat setting by approx. 0.3 bar. Increase of superheat setting results in a lower MOP value and vice versa.

# Honeywell

#### Automation & Control Solutions

Honeywell GmbH Hardhofweg 74821 Mosbach/Germany Phone: +49 (0) 62 61 / 81-475 Fax: +49 (0) 62 61 / 81-461 E-Mail: cooling.mosbach@honeywell.com www.honeywell-cooling.com